



FLEXIHEAT UK LTD
www.flexiheatuk.com
01202 822221

Installation, Use and Maintenance Manual for models

R2K RAIN

R2K 24 RAIN / R2K 28 RAIN / R2K 34 RAIN

Condensing boiler, with integrated heat exchanger for domestic hot water production, suitable for outdoor installation

CE 0476

SUMMARY

INTRODUCTION.....	4
-------------------	---

1. INSTALLER SECTION 7

1.1. INSTALLATION	8
1.1.1. GENERAL INSTALLATION WARNINGS.....	8
1.1.2. BOILER LOCATION ENVIRONMENTAL REQUIREMENTS.....	9
1.1.3. REFERENCE LEGISLATION.....	9
1.1.4. OVERALL DIMENSIONS.....	10
1.1.5. HYDRAULIC CONNECTIONS.....	10
1.1.6. POSITIONING AND MINIMAL TECHNICAL SPACES.....	11
1.1.7. PUMP HEAD / FLOW DIAGRAM.....	13
1.1.8. HYDRAULIC CONNECTION.....	14
1.1.9. SYSTEM FILLING.....	16
1.1.10. FILLING THE CONDENSATE SIPHON.....	18
1.1.11. FROST PROTECTION.....	19
1.1.12. GAS CONNECTION.....	20
1.1.13. ELECTRICAL CONNECTION.....	20
1.1.14. POWER SUPPLY.....	22
1.1.15. OPTIONAL ELECTRICAL CONNECTIONS.....	23
1.1.16. FLUE SYSTEMS.....	28
1.1.17. INSTALLATION MODES.....	29
1.1.18. TYPES OF FUME EXHAUST SYSTEMS.....	31

2. SERVICE CENTRE SECTION 35

2.1. FIRST START-UP	36
2.1.1. PRELIMINARY OPERATIONS FOR FIRST START-UP.....	36
2.1.2. BOILER COMMISSIONING.....	37
2.1.3. CO ₂ VALUE CHECK AND CALIBRATION.....	38

SUMMARY

2.1.4. ELECTRIC FAN FREQUENCY/HEAT CAPACITY DIAGRAM	40
2.2. MAINTENANCE	43
2.2.5. GENERAL MAINTENANCE WARNINGS	43
2.2.6. TECHNICAL DATA	45
2.2.7. TECHNICAL ASSEMBLY	53
2.2.8. HYDRAULIC BOARD	55
2.2.9. WIRING DIAGRAM	56
2.2.10. ACCESSING THE BOILER	57
2.2.11. ACCESSING THE ELECTRONIC BOARD	58
2.2.12. SYSTEM EMPTYING	59
2.2.13. GAS CONVERSION	60

3. USER SECTION 63

3.1. USE	64
3.1.1. GENERAL USE WARNINGS	64
3.1.2. CONTROL PANEL	66
3.1.3. DISPLAY ICONS	67
3.1.4. INFO MENU DISPLAY DATA	68
3.1.5. START-UP	70
3.1.6. OPERATING MODE	70
3.1.7. INFORMATIONAL NOTE ON ANTI-FREEZE FUNCTION	72
3.1.8. SYSTEM FILLING	73
3.1.9. FAULT SIGNALLING CODES	74
3.1.10. ACTIVE FUNCTIONS SIGNALLING CODES	77
3.1.11. FAST H2O FUNCTION	77
3.1.12. MAINTENANCE	78
3.1.13. EXTERNAL CASING CLEANING	78
3.1.14. DISPOSAL	78

INTRODUCTION

WARNING

Before starting any operation it is mandatory to read this instruction manual, in relation to the activities to be carried out as described in each relevant section. Proper operation and optimal performance of the boiler are ensured by strict compliance with all the instructions given in this manual.

The installation, use and maintenance manual is an integral and essential part of the product and must be delivered to the user.

MANUAL USERS

The manual users are all those who install, use and maintain the boiler.

The boiler must be used and accessed only by qualified operators that fully read and understood the use and maintenance manual, paying particular attention to the warnings.

READING AND SYMBOLS OF THE MANUAL

To ease the understanding of this manual, recurrent symbols where used, in particular:

- › On the outer margin of the page is placed a thumb index indicating the type of user to which the

instructions in that section address.

- › The titles are differentiated by thickness and size in accordance with their hierarchy.
- › The images contain important parts described in the text, marked with numbers or letters.
- › (See chap. "chapter name"): this entry indicates another section in the Manual that you should refer to.
- › Device: this term is used referring to the boiler.



DANGER

It identifies an information related to a general danger that if not complied with, may cause serious personal damage or even death.



ATTENTION

It identifies an information that if not complied with may cause small or medium level lesions to the person or serious deterioration to the boiler.



WARNING

It identifies a precaution information that must be observed in

1. INTRODUCTION

order to avoid damaging the machine or parts of it.

MANUAL STORAGE

The manual must be carefully stored and replaced in case of deterioration and/or low legibility.

If you misplace the use and maintenance manual, you can request it from the Service Centre giving the serial number and model of the boiler indicated on the data plate placed on the right side of its casing.

As an alternative, the use and maintenance manual can be downloaded free of charge from the on-line site www.radiant.it, accessing the “download” section and entering the boiler model.

MANUFACTURER WARRANTY AND RESPONSIBILITY

The warranty of the Manufacturer is provided only through its own authorized Service Centres, listed on the official web site (www.radiant.it), and covers all conformity defects at the moment of sale.

The technical and functional features of the device are ensured by its use in compliance:

1. with the use and maintenance instructions contained in the manuals accompanying the product, the content of which the customer certifies that he is aware;
2. with the conditions and purposes to which devices of the same type are intended.

For more information on the warranty validity, its duration, the obligations and the exemptions, please consult the First start-up certificate attached to this manual.

The manufacturer reserves:

- > the right to modify the tools and relative technical documentation without any obligation to third parties; neither will the company be held responsible for any inaccuracies in this handbook deriving from printing or translation errors;

1. INTRODUCTION

- › the material and intellectual ownership of this manual and forbids its distribution and duplication, even partial, without prior written authorization.

PRODUCT CONFORMITY

RADIANT BRUCIATORI spa declares that its gas boilers comply with the European Directives and with the requirements provided in the European standards below:

- › Eco-design Directive 2009/125 CE,
- › Energy labelling Directive 2010/30/CE,
- › Regulation EU 811/2013,
- › Regulation EU 813/2013,
- › Regulation EU 2016/426,
- › Electromagnetic compatibility Directive 2014/30/CE,
- › Performance Directive 92/42/CE,
- › Low voltage Directive 2014/35/CE.

The materials used such as copper, brass, stainless steel create a homogeneous, compact and functional assembly, easy to install and manage. In its simplicity, the boiler is equipped with all accessories necessary to render it a veritable independent heating unit. All boilers are tested and delivered with a quality certificate signed by the tester.

1. INSTALLER SECTION

The installation operations described in this section, must be performed only by qualified personnel, having the appropriate technical training in the field for the installation and maintenance of components of civil and industrial domestic hot water production and heating plants.

1. INSTALLATION

1.1. INSTALLATION

1.1.1. GENERAL INSTALLATION WARNINGS



ATTENTION

This boiler may be used only for the purpose for which it has been designed: heat water to a temperature below boiling point at atmospheric pressure. Any other use is considered wrong and dangerous. The manufacturer is excluded from any contractual or extra-contractual responsibility for damages caused to people, animals or property due to errors during installation.



ATTENTION

This boiler must be installed only by qualified personnel, having the appropriate technical training in the field for the installation and maintenance of components of civil and industrial domestic hot water production and heating plants.



ATTENTION

After having removed the packing, make sure the device is intact. In case of doubt, do not use the device and contact the supplier.

BEFORE INSTALLING THE BOILER, THE INSTALLER MUST MAKE SURE THAT THE FOLLOWING CONDITIONS ARE MET:

- › The device is connected to a heating system and a water supply network appropriate for its power and performance.
- › The location must be properly vented through an air vent.
- › The air vent must be placed at floor level to prevent it from being obstructed, protected by a grid that does not hamper the useful passage section.
- › The device is suitable for use with the type of gas available by checking the boiler data plate (placed on the inner side of the front casing).
- › Make sure that the pipes and joints are perfectly sealed, without any gas leaks.
- › Make sure that the grounding system works properly.
- › Make sure that the electrical system is suitable for the maximum power absorbed by the device, value indicated on the data plate.

1. INSTALLATION



WARNING

Use only original RADIANT optional or kit accessories (including ones).

1.1.2. BOILER LOCATION ENVIRONMENTAL REQUIREMENTS

The device installation location should be vented due to the presence of threaded joints on the gas supply line. The location should be therefore provided with vents as to ensure air exchange, with output grid in the natural accumulation area of potential gas losses.



WARNING

DO NOT install the boiler in a technical compartment near a swimming pool or a laundry, to avoid that the combustion air is exposed to chlorine, ammonia or alkaline agents that may worsen the corrosion phenomenon of the heat exchanger. Failure to observe this caution will void the warranty of the heat exchanger.

The ABS material boiler casing is approved for the exposition to atmospheric agents and, in particular, to UV rays.

THIS BOILER IS ABLE TO OPERATE WITHIN THE AMBIENT TEMPERATURES MINIMUM -10 °C AND MAXIMUM 60 °C.



WARNING

If the temperature in the appliance installation location goes below -10 centigrades, please fill the plant with anti-freeze liquid and insert and a frost protection kit (see chapter 'ANTI-FREEZE PROTECTION').



WARNING

The manufacturer will not be held responsible for damages caused by incorrect installation not in conformity with the above mentioned instructions and not duly protected from freeze.


1.1.3. REFERENCE LEGISLATION

The installation must be done according to the requirements of current legislation and in compliance with local technical regulations, according to the indications of the good technique.


1. INSTALLATION

INSTALLER

1.1.4. OVERALL DIMENSIONS



1.1.5. HYDRAULIC CONNECTIONS



1. INSTALLATION

1.1.6. POSITIONING AND MINIMAL TECHNICAL SPACES

The boiler must be installed only on a vertical solid wall, able to sustain its weight.



In order to allow the access inside the boiler for maintenance operations, the minimum technical spaces indicated in figure 1 have to be respected.

To facilitate the installation, the boiler is provided with wall template that allows setting in advance the connections to the pipes, offering the possibility to connect the boiler once masonry works are completed.

For boiler positioning, proceed as follows (see fig. 2):

1. Trace a line using a spirit level (min. length 25 cm) on the installation wall;
2. place the top of the template along the traced line respecting the distances of the water connections; then mark the two points to insert the two wall fastening screws, then trace the points for the flue system;
3. remove the template and drill the wall;

4. hang the boiler onto the wall fastening screws or onto the wall hanging bracket and perform the connections.




1. INSTALLATION




WARNING


Make sure, using a spirit level, that the boiler is properly inclined being levelled (see fig.3) so as to allow the condensate to drain.



1.1.7. PUMP HEAD / FLOW DIAGRAM



--- Appliance head losses



Fixed head selection button at maximum speed
(It disables the control from the PWM)

1. INSTALLATION

1.1.8. HYDRAULIC CONNECTION



DANGER

Make sure that the water and heating pipes are not used as grounding system for the electrical plant. They are not suitable for such use.



WARNING

To prevent voiding the warranty and ensure proper operation of the boiler, please wash the system (if possible when hot) with suitable pickling or descaling solutions in order to remove the impurities coming from pipes and radiators.



WARNING

If the boiler is installed in a hydrostatic position lower than those of the connected devices (radiators, fan coils, etc.), install the shut-off valves on the D.H.W. and heating circuits to ease the performance of the maintenance operations, if it is necessary only to empty the boiler.



WARNING

When connecting the boiler to water supply, avoid excessive bending and recovery operations from any off axis positioning that may

damage the pipes causing leaks, malfunction or early wear.



WARNING

In order to avoid any vibrations and noises, do not use pipes with small diameters or elbows with small radius and significant cut-off of the passage sections.



WARNING

Connect the boiler safety drains to a discharge funnel. The manufacturer is not responsible for any floods due to safety valve opening in case of plant overpressure.

D.H.W. CIRCUIT



WARNING

In order to avoid any limescale and damages to the D.H.W. heat exchanger, the domestic inlet water should be treated in accordance with the legislation in force. According to the D.P.R. 59/09, it is mandatory to treat the water over 15° French for domestic water, by means of chemical (according to UNI 8065) conditioning treatment for powers < 100 kW or softening treatment for powers > 100 kW. Moreover, it is necessary to install a protection security filter of the system.



WARNING

The pressure of the cold inlet water should be between 0.5 and 6 bar. In case of higher pressure values, please install a pressure reducer upstream from the boiler.

property for failure to comply with these instructions.

HEATING CIRCUIT



WARNING

In order to avoid any scale or deposits on the primary exchanger, the heating circuit inlet water should be treated in accordance with the legislation in force. According to the D.P.R. 59/09, it is mandatory to treat the water over 25° French for the heating circuit by means of chemical (according to UNI 8065) conditioning treatment for powers < 100 kW or softening treatment for powers > 100 kW. Moreover, it is necessary to install a protection security filter of the system.



WARNING

In case the boiler is installed as part of a low temperature circuit, please install a safety thermostat on the heating flow, which can stop the boiler activity in case of high heating flow temperature. The company assumes no liability for damages caused to persons or

1. INSTALLATION

1.1.9. SYSTEM FILLING



WARNING

For system filling use only clean tap water.



WARNING

If the system is filled by adding ethylene glycol-type chemical agents, the installation of a hydraulic separator on the loading system is recommended, in order to separate the heating circuit from the D.H.W. circuit.

Before powering up the boiler, fill the system as follows:

1. slightly loosen the cap of the pump air vent valve (1-fig. 1) to release the air from the system;
2. slightly loosen the cap of the air vent valve placed on top of the condensing exchanger (fig. 3) to release the air from the top of the system;
3. open the filling tap "R" (fig. 2);
4. release all the air;
5. use pressure gauge "M" (fig. 2) to make sure that the system pressure reaches 1.2 bar (fig. 4);
6. after performing this operation, make sure that the filling tap "R" (fig. 2) is properly closed.
7. open the air relief valves of the radiators and check the air




fig. 1




fig. 2





fig. 3

1. INSTALLATION

8. removal process. **WHEN THE WATER COMES OUT, CLOSE THE RADIATOR AIR VENT VALVES AND THE AIR VENT VALVE LOCATED IN THE UPPER RIGHT PART OF THE CONDENSING EXCHANGER (FIG. 3).**
9. If after performing these operations, there is a decrease of the water pressure inside the system, open the filling tap "R" once again, until the pressure gauge indicates the value of 1.2 bar (fig. 4).



INSTALLER


1. INSTALLATION

1.1.10. FILLING THE CONDENSATE SIPHON

Before starting the boiler, it is necessary to fill the condensate siphon in order to avoid flue reflux of combusted gases through the siphon itself.

Fill the condensate siphon as follows (see fig. 5):

- > With a glass pour the water in the heat exchanger's flue exhaust duct outlet (see fig. 5), up to fill the condensate siphon to the highest point "T" (fig. 5);
- > Connect the dedicated flexible condensate draining pipe to a waste disposal system. The condensate can be drained directly in the sewerage system by inserting an easily serviceable siphon.



1. INSTALLATION

1.1.11. FROST PROTECTION

The boiler is protected against freezing thanks to the P.C.B. configuration with functions that start the burner and heat the concerned parts when their temperature goes below the minimum pre-set values, protecting the boiler up to an external temperature of -10 °C.

The boiler starts when the heating water temperature goes below 8 °C (this value can be modified through parameter P31), automatically starting the burner until the heating flow water temperature reaches the 30°C and, in presence of a return sensor, until the heating return water temperature reaches the 20°C.

The system starts even if on the display appears "OFF", as long as the boiler is connected to the power (230 V) and gas supply.

For long periods of standby, please empty the boiler and the system.

If the temperature goes below -10° centigrades, please fill the system with anti-freeze liquid (CLEANPASS FLUIDO AG cod. 98716LA) and insert a frost protection kit (cod. 82259LP).

CLEANPASS DILUTION PERCENTAGE	FLUIDO AG
ANTI-FREEZE - PROPYLENE GLYCOL	FREEZING POINT
(%) VOLUME	(°C)
20	-7.5
30	-13
35	-18
40	- 22.5
45	-28
50	-33.5
55	-42
60	-50
RECOMMENDED GLYCOL PERCENTAGE: 20 %	MINIMUM

INSTALLER

1. INSTALLATION

1.1.12. GAS CONNECTION



DANGER

In order to connect the boiler gas connector to the supply pipe, use a stop seal of an appropriate size and material. The use of hemp, teflon tape or similar materials is strictly forbidden.

BEFORE PERFORMING THE GAS CONNECTION, MAKE SURE THAT:

- › the gas supply line complies with the standards and regulations in force;
- › the piping section suits the requested capacity and its length;
- › the piping is equipped with all safety and control devices required by the standards in force;
- › the internal and external seals of the gas inlet system are checked;
- › the boiler is suitable for use with the available type of gas by checking the boiler data plate (placed on the inner side of the front casing. If they do not match, please take the necessary measures to adapt the boiler to another type of gas (see chapter GAS CONVERSION));
- › the gas supply pressure falls within the values indicated on the data plate.

1.1.13. ELECTRICAL CONNECTION



DANGER

The boiler is electrically safe only if it is properly connected to an efficient earthing system, performed in compliance with the safety standards in force. Check this essential safety requirement is strictly recommended. If in doubt, request an accurate check of the electrical system performed by qualified staff, as the manufacturer is not responsible for any damages caused by lack of earthing system.

- › Make sure that the electrical systems is suitable for the maximum power absorbed by the boiler, value indicated on the data plate.
- › make sure that the cables section is appropriate for the maximum power absorbed by the boiler and that it is however not lower than 1 mm².

1. INSTALLATION

- > The equipment works with alternating current of 230 V and 50 Hz. The electrical connection must be performed using an all-pole switch with an opening of at least 3 millimetres between contacts placed upstream from the device.



WARNING

Make sure that the live and neutral cables connection is performed in compliance with the wiring diagram (see chapter POWER SUPPLY).



WARNING

It is strictly forbidden the use of adaptors, multiple plugs and/or extensions for the general power supply of the boiler from the electrical network.

1. INSTALLATION

1.1.14. POWER SUPPLY

To power the boiler, connect the electrical cables to the terminal block the control panel as follows:




DANGER

Cut off the voltage from the main switch.


- > remove the boiler front casing (refer to chapter ACCESSING THE BOILER).
- > loosen the two screws and remove the plate "A" (see fig. 1).
- > after removing the plate, connect the electrical cables to terminal block "B" (see fig. 1):
 - the yellow/green cable to the terminal marked with grounding symbol "⊕".
 - the blue cable to the terminal marked with "N".
 - the brown cable to the terminal marked with "L".

After performing these operations, remount plate "A" and the front casing.



1.1.15. OPTIONAL ELECTRICAL CONNECTIONS

The cables should be inserted inside the boiler using the fairleads 'P1' and 'P2' placed on the hydraulic connections bottom plate (see fig. 1). Make a hole on the fairlead, smaller than the cable diameter, to make sure that the air cannot pass through.



To wire the optional items below:

- **(SE) OUTDOOR TEMPERATURE SENSOR CODE 73518LA**
- **(TA) ROOM THERMOSTAT**
- **(CR) OPEN THERM REMOTE CONTROL CODE 40-00017**

operate on the terminal block placed inside the control panel as follows:



DANGER


Cut off the voltage from the main switch.


- > remove the boiler front casing (see chapter ACCESSING THE BOILER); unscrew the screws and remove plate "A" (see fig. 2).
- > After removing the plate, connect the electrical cables to terminal block "B" (see fig. 2):

1. INSTALLATION

- For the outdoor temperature sensor connect the two non-polarized conductors to the Se-Se contacts.
- For the room thermostat or remote control, first remove the bridge on the Ta-Ta contacts and then connect the two non-polarized conductors to the Ta-Ta contacts.

After performing these operations, remount plate "A" and the front casing.



NB: In case of simultaneous presence of outdoor sensor and remote control, the main P.C.B. only sends the external temperature value to the remote device without using it for modulation. The communication between P.C.B. and the remote control takes place independently from the boiler's operating mode and after establishing the connection, the user interface on the P.C.B. is disabled and the display shows the symbol .

1. INSTALLATION

To wire the optional items below:

- **(TP) EXCLUSION OF THE D.H.W. OR HEATING CIRCUIT VIA CLEAN CONTACT (SEE EXPLANATION IN THE PARAGRAPH 'EXCLUSION VIA CONTACT (TP)')**

- **(CT) TELEPHONE DIALER OR AIR PRESSURESWITCH (SEE CONTACT MANAGEMENT IN THE PARAMETER P36)**

- **BUS 0-10V**

- **(SVZ) ZONE VALVES MANAGEMENT KIT CONNECTED TO A REMOTE CONTROL COD. 65-00030**

- **(AG) AUXILIARY RELAY FOR GENERIC DEVICE. MAXIMUM CURRENT 3A WITH 250VAC (SEE RELAY MANAGEMENT AT PARAMETER P34)**

operate on the P.C.B. placed inside the control panel as follows:



DANGER

Cut off the voltage from the main switch.

- > remove the boiler front casing [refer to chapter ACCESSING THE BOILER].

- > remove the control panel back plate (see chapter ACCESSING THE P.C.B.).

- > after removing the back plate, connect the items below to the P.C.B. (see fig. 1).

After performing these operations, remount the back plate and the front casing.

1. INSTALLATION

INSTALLER




fig. 1

RA:	AUXILIARY RELAY	GR:	GREY
TAZ1:	ROOM THERMOSTAT ZONE 1	AR:	ORANGE
TAZ2:	ROOM THERMOSTAT ZONE 2	NE:	BLACK
VZ1:	ZONE VALVE 1	MA:	BROWN
VZ2:	ZONE VALVE 2	CE:	BLUE
VZR:	REMOTE CONTROLLED ZONE VALVE	RO:	RED

EXCLUSION VIA CONTACT (TP)

In case there is a tank clock or a temperature thermostat connected on contacts n.55-56 of the M14 terminal board on the P.C.B., when the contact (TP) is closed, one of the following functions or requests can be excluded:

FAST H2O FUNCTION – if parameter P01 value is set to '0', '1' or '4' (see chapter 'DIGITECH CS PARAMETERS TABLE') and FAST H2O function is active, the function is deactivated when closing the contact.

D.H.W. REQUEST – if parameter P01 value is set to '0' or '1' and parameter P17 value is set to '1' (see chapter 'DIGITECH CS PARAMETERS TABLE'), the burner ignition request in D.H.W. mode is disabled, when closing the contact. If FAST H2O function is active, the function is deactivated when closing the contact.

TANK RESTORATION – if parameter P01 value is set to '2' or '3' (see chapter 'DIGITECH CS PARAMETERS TABLE'), the tank restoration function is deactivated, when closing the contact. Upon D.H.W. request through flow-switch, the boiler activates in instantaneous mode.

HEATING REQUEST – if parameter P01 value is set to '5' (see chapter 'DIGITECH CS PARAMETERS

TABLE'), the burner ignition request in heating mode is disabled, when closing the contact (even if the request comes from a connected room thermostat or remote control).

1. INSTALLATION

1.1.16. FLUE SYSTEMS



WARNING

To ensure correct operation and perfect efficiency values of the appliance, it is essential to connect the boiler flue exhaust pipe to the flue exhaust duct using dedicated polypropylene flue kits and accessories for condensing boilers. It is recommended to install Radiant approved flue systems.



WARNING

Conventional (aluminium) flue components cannot be used for the flue exhaust of condensing boilers, nor vice versa.




WARNING

For fumes exhaust and condensate collection, please follow the technical standards in force.

- › For all discharge ducts, with regard to the fumes path, you should provide an uphill slope (outwards) so as to favour the reflux of the condensate towards the combustion chamber, suitably realized to collect and drain acid condensate.
- › For all air suction ducts, with regard to the air path, you should provide an uphill slope (towards

the boiler) so as to avoid the protrusion inside the duct of rain water, dust or foreign objects.

- › In case of horizontal co-axial system installation, correctly place the horizontal co-axial terminal suitably realized to respect the slopes inside the fumes duct and to protect the air suction duct from adverse weather conditions.
- › In order to discharge the fumes through a fumes exhaust duct carefully follow the technical standards in force.
- › Make sure that the discharge tube does not protrude inside the fumes exhaust duct, stop before it reaches the inner surface of the latter.
- › The discharge duct must be perpendicular with the opposite internal wall of the chimney or of the fumes exhaust duct (fig. 1).




1. INSTALLATION

1.1.17. INSTALLATION MODES

For this type of boiler are available the following fumes discharge configurations: A3, B23, B23p, B33, B53 and C13 [see Fig. 1].

- > A3- Outdoor suction and outdoor discharge.
- > B23- Indoor suction and outdoor discharge.
- > B23P- Indoor suction and outdoor discharge, with exhaust system operating under pressure.
- > B33- Indoor suction and fumes exhaust duct discharge.
- > B53- Indoor suction and outdoor discharge through own fumes exhaust duct.
- > C13- Concentric wall discharge.

fig. 1



DISCHARGE OF COMBUSTION PRODUCTS FOR B-TYPE DEVICES

The gas devices, provided with connection for fumes exhaust tube, must be directly connected to efficient chimneys or fume exhaust ducts: only if these are missing you can discharge the combustion products directly through the wall.

The connection to the chimney or to the fume exhaust ducts must respect the following requirements:

- Be sealed and realised in materials suitable to resist normal mechanical stress, heat, the action of combustion products and any condensate forming;
- have no more than three changes in direction, including the chimney and/or fume exhaust duct inlet connection, made with internal angles greater than 90°. The changes in direction must be made only by using curved elements;
- have the axis of the inlet end perpendicular to the internal wall opposite to the chimney or fume exhaust duct;
- have, along its entire length, a section equal to or greater than that of the connection of the device discharge tube;

1. INSTALLATION

- have no shut-off devices (shutters).
- for direct external discharge there must be no more than two changes in direction.

LOCATIONS VENTING FOR B-TYPE DEVICES

The locations in which are installed gas devices must be vented so as to ensure the amount of air necessary for a regular combustion and for location ventilation. The natural air intake must take place directly through:

- permanent openings on the external walls of the location (windows);
- single or collective, ramified ventilation ducts.

The openings on the external walls of the location must respect the following requirements:

- have a net overall free passage section of at least 6 cm^2 for every kW of heat capacity installed with a minimum of 100 cm^2 ;
- they must be realized so as to make sure that the opening inlets are not obstructed (neither indoors nor outdoors);
- they must be protected with grids, metal meshes, etc. so

- as to keep the useful section mentioned above.
- they must be placed at a height next to the floor level such as to allow proper operation of the combustion products discharge systems; if such position can not be obtained, please increase by at least 50% the section of the vents.

1.1.18. TYPES OF FUME EXHAUST SYSTEMS

KIT RAIN - Ø 80 HORIZONTAL POLYPROPYLENE PIPE. OUTSIDE INSTALLATION

It allows the flue discharge through the exhaust pipe and the air intake from the environment.

Suitable only for condensing boilers.

It allows the combustion flues discharge through a polypropylene pipe and the air exhaust directly from the hole situated on the room sealed chamber plate protected by a metal net.


PLEASE SEE THE MAXIMUM DISCHARGE LENGTH IN THE TABLE IN CHAPTER "TECHNICAL DATA".

The maximum discharge length (or linear reference length) can be calculated summing the length of the linear tube and that equivalent to each additional curve with respect to the first.

Subsequent addition of a curve is similar to adding a linear length of tube according to the indications below:

co-axial curve Ø80 to 90° = 1.5 m

co-axial curve Ø80 to 45° = 0.8 m



1. INSTALLATION

KIT RAIN L - Ø 80 VERTICAL POLYPROPYLENE PIPE. OUTSIDE INSTALLATION

It allows the flue discharge from the roof e and the air input from the environment.

Suitable only for condensing boilers. It allows the combustion flues discharge through a polypropylene pipe and the air exhaust directly from the hole situated on the room sealed chamber plate protected by a metal net.


PLEASE SEE THE MAXIMUM DISCHARGE LENGTH IN THE TABLE IN CHAPTER "TECHNICAL DATA".

The maximum discharge length (or linear reference length) can be calculated summing the length of the linear tube and that equivalent to each additional curve with respect to the first.

Subsequent addition of a curve is similar to adding a linear length of tube according to the indications below:

co-axial curve Ø80 to 90° = 1.5 m

co-axial curve Ø80 to 45° = 0.8 m




1. INSTALLATION

FRONTAL FLUE KIT FOR RAIN SERIES - Ø 60 POLYPROPYLENE HORIZONTAL PIPE FOR OUTDOOR INSTALLATIONS WITHOUT FLUE CHIMNEY.

Suitable only for condensing boilers. It allows the outside combustion flues discharge through a polypropylene pipe, and the air intake directly from the hole which is situated on the room sealed chamber plate, which is protected by a wire mesh.

PLEASE NOTE: during the flue analysis tests, place the analyser inside the frontal flue kit terminal slots 'F' (fig. 2).



2. SERVICE CENTRE SECTION

All operations described below relative to first start-up, maintenance and replacement should be performed only by qualified personnel

2.1. FIRST START-UP

2.1.1. PRELIMINARY OPERATIONS FOR FIRST START-UP

The first start-up operations consist in checking the correct installation, adjustment and operation of the device. Proceed as follows:

- › check the inner system sealing in accordance with the indications provided by standard and regulations in force;
- › check if the gas used is suitable for the boiler;
- › check if the gas capacity and relative pressures comply with those on the plate;
- › check the intervention of the safety device in case of lack of gas;
- › make sure that the device supply voltage corresponds with that on the plate (230 V – 50 Hz) and that the wiring is correct;
- › make sure that the grounding system works properly;
- › make sure that the combustion air addition and fumes and condensate discharge take place properly in compliance with the Local and National Laws and Standards in force;
- › make sure that the fumes discharge tube and its connection to the fume exhaust duct comply with the requirements of the Local and National Laws and Standards;
- › make sure that the heating system gate valves are open;
- › make sure that there is no intake of gaseous products within the system;
- › make sure that there are no flammable liquids or materials near the device;
- › open the boiler gas tap and make sure that there are no gas leaks upstream from the device (the burner gas connection must be checked while the machine is running);
- › in case of new installation of the gas supply network, the air inside the tubes may block the device at its first start-up. You might have to repeat the start-up procedure to purge all the air inside the tube.

2.1.2. BOILER COMMISSIONING



WARNING

Make sure that the system is correctly filled.



Proceed with boiler commissioning as follows:

Make sure the gas feed valve is switched off

> Power the boiler.

THE START-UP SYSTEM WILL AUTOMATICALLY ACTIVATE THE SYSTEM AIR RELIEF CYCLE FUNCTION DISPLAYED ON SCREEN WITH CODE "F33" (ONLY AT FIRST START-UP WILL LAST FOR 5 MINUTES*). When function "F33" is active, the pump is enabled and the burner start-up request is disabled. The boiler can work normally only after completing the operation.

- > Make sure the circulating pump is unblocked.
- > If it should be blocked, wait for the circulating pump to activate the automatic reset (lasting 3 min.)
- > If the circulating pump should be still blocked, activate the circulating pump automatic reset again (further 3 minutes), and switch off the power supply and switch it on again.
- > Open the gas tap.

- > Use the button  to select the desired operation mode. If the symbol is displayed fixed, it means that the function has been activated.
- > The burner will start as soon as the thermostat contact is closed ;
- > If the flame is missing, the board will repeat the start-up operations after post-ventilation (20 seconds).
- > You might have to repeat the start-up operation several times to release all the air inside the gas tube. Before repeating the operation, wait at least 5 seconds from the last start-up attempt and unlock the boiler from "E01" error code by pressing the Reset  key.

(*) The boiler performs the system venting cycle function (5 minutes) only during the first starting. After every water pressure reset the boiler will automatically perform a reduced system venting cycle (2 minutes). During this function the display shows F33 code. The correct boiler operation will be allowed only after this operation has been completed.

2. FIRST START-UP

2.1.3. CO₂ VALUE CHECK AND CALIBRATION



WARNING

The CO₂ value should be checked with the casing assembled, while the gas valve should be adjusted with the casing open.

To check and calibrate the CO₂ value to minimum and maximum heating power proceed as follows:

FOR MINIMUM HEATING POWER

- › Activate the chimney sweeper function (F07) by keeping pressed the key **(R)** for 7 seconds (the maximum time of this function is 15 minutes).
- › Insert the fumes analyser probe in the suitable 'PF' fumes inlet (fig. 1), then make sure that the CO₂ value complies with the requirements indicated in chapter "Technical data", otherwise unscrew the protection screw 'A' (fig. 2) and adjust using a 4 Allen wrench the screw '2' (fig. 2) of the Off-Set adjuster. To increase the CO₂ value, turn the screw clockwise and vice-versa if you want to decrease it. Once completed the adjustment, tighten the protection screw 'A' (fig. 2) on the Off-Set adjuster.

fig. 1










fig. 2




2. FIRST START-UP

FOR MAXIMUM HEATING POWER

- › Press the key  of the heating temperature setting , to adjust the maximum heating power.
- › Make sure that the CO₂ value complies with the indications in "Technical data", otherwise adjust using screw '1' (fig. 2) of the gas flow adjuster. To increase the CO₂ value, turn the screw anti-clockwise and vice-versa if you want to decrease it.
- › After each adjustment variation on screw '1' (fig. 2) of the gas flow adjuster you have to wait for the boiler to stabilize itself to the set value (about 30 seconds)..
- › Press the key  of the heating temperature setting  and make sure that the CO₂ value did not change to minimum, if changed repeat the calibration described in the previous paragraph.
- › Deactivate the chimney sweeper function by selecting the OFF mode by using the key .

2. FIRST START-UP


2.1.4. ELECTRIC FAN FREQUENCY/HEAT CAPACITY DIAGRAM



SERVICE CENTRE


GAS TYPE		MINIMUM FREQUENCY	MAXIMUM FREQUENCY	STARTING STEP ADJUSTMENT
G20	Hz	50	190	110
G30	Hz	50	177	130
G31	Hz	50	190	130

2. FIRST START-UP



GAS TYPE		MINIMUM FREQUENCY	MAXIMUM FREQUENCY	STARTING STEP ADJUSTMENT
G20	Hz	50	192	110
G30	Hz	50	180	130
G31	Hz	50	190	130

2. FIRST START-UP



SERVICE CENTRE

GAS TYPE		MINIMUM FREQUENCY	MAXIMUM FREQUENCY	STARTING STEP ADJUSTMENT
G20	Hz	53	203	110
G30	Hz	55	195	130
G31	Hz	55	203	130

2.2. MAINTENANCE

2.2.5. GENERAL MAINTENANCE WARNINGS



DANGER

Before each components cleaning or replacement operation, ALWAYS cut off the POWER, WATER and GAS supply of the boiler.



WARNING

To ensure greater life span and proper operation of the device, during the maintenance operations use only original spare parts.



ATTENTION

To ensure the efficiency and safety of the device, the maintenance operations must be realized on an annual basis. The operations described below, are essential to the validity of the standard RADIANT warranty and must be performed by professionally qualified personnel in accordance with current legislation and authorized by RADIANT.

Please perform the following operations once a year:

- > Check that the system's water PH is between 6.5 and 8.5;
- > check the pre-load pressure of the expansion vessel;
- > check the sealing of the water components, and replace if necessary the gaskets;
- > check that the wiring is performed in compliance with the requirements in the boiler instruction manual;
- > check the wiring inside the control panel;
- > remove and clean the burner from oxidation;
- > check the integrity and the position of the sealed chamber sealing gasket;
- > check the primary exchanger, if necessary, clean it;
- > check the operation of the gas light up and safety systems. If necessary, remove and clean the flame detection and light up electrodes from incrustations paying attention to respect the distances with respect to the burner;
- > check the sealing of the gas components, and replace if necessary the gaskets;
- > visually check the flame and the condition of the combustion chamber;
- > if necessary make sure that the combustion is suitably adjusted and

2. MAINTENANCE

if required proceed as indicated in section "CO2 VALUE CHECK AND CALIBRATION";

- › periodically check the integrity of the fume exhaustion system for safety and proper operation;
- › make sure that the permanent ventilation outlets are present, correctly sized and functioning, based on the installed devices. Respect the requirements provided by Local and National legislation;
- › check the heating circuit safety systems: limit temperature safety thermostat; limit pressure safety;
- › check the proper operation of the condensate draining system, including the devices outside the boiler such as condensate collection devices installed along the path of the fume exhaust duct or neutralization devices for acid condensate. Check that the liquid flow is not obstructed and that there are no combustion gas refluxes inside the internal system;
- › check the flow and temperature of domestic hot water.

2. MAINTENANCE

2.2.6. TECHNICAL DATA

Model		R2K 24 Rain	R2K 28 Rain	R2K 34 Rain
CE certification	no.		0476CQ0134	
Gas category		II2H3P		
Flue system type	type	A3-B23-B23p-B33-B53-C13		
Energy efficiency 92/42 CEE	no. stars	4	4	4
Energy efficiency EN13203-1	no. stars	3	3	-
Heat Input max [C.H.]	kW	23,50	28	34
Heat Input max [D.H.W.]	kW	23,50	28	34
Heat Input min [C.H.]	kW	2,90	3,70	4,10
Heat Input min [D.H.W.]	kW	2,90	3,70	4,10
Heat Input min LPG	kW	2,90	3,70	4,10
Heat Output max. - 60/80°C	kW	22,94	27,30	33,35
Heat Output min. - 60/80°C	kW	2,75	3,52	3,94
Heat Output max. - 30/50°C	kW	24,79	29,40	36,19
Heat Output min. - 30/50°C	kW	3,02	3,83	4,34
Heat Output max at 30% Heat Input average - return 30°C	kW	4,26	5,12	6,21
Efficiency at 100% Heat Input - 60/80°C	%	97,60	97,50	98,08
Efficiency at 30% Heat Input - return 30°C	%	107,60	107,80	108
Heat Input average efficiency - 60/80°C	%	97,20	96,80	98,02
Heat Output max at 30% Heat Input average - return 47°C	%	-	-	102,14
Efficiency at 30% Heat Input average - return 30°C	%	107,70	107,70	108,60
Efficiency Heat Output min. - 60/80°C	%	94,70	95,00%	96,06
Efficiency at 100% Heat Input - 30/50°C	%	105,50	105	106,43
Efficiency Heat Output min - 30/50°C	%	104,20	103,60	105,91
Maximum combustion efficiency	%	97,80	97,70	97,60
Minimum combustion efficiency	%	98,10	98,20	97,90

2. MAINTENANCE

Model		R2K 24 Rain	R2K 28 Rain	R2K 34 Rain
Flue efficiency losses with burner on (Heat Input max.)	%	2,20	2,30	2,40
Flue efficiency losses with burner on (Heat Input min.)	%	1,90	1,80	2,10
Fumes temperature - Heat Input max.	°C	64,30	68,17	69,40
Fumes temperature - Heat Input min.	°C	58,50	60,70	61,30
CO2 - Heat Input max. - G20	%	9,30 - 9,10	9,30 - 9,10	9,45 - 9,25
CO2 - Heat Input min. - G20	%	9 - 8,80	9,00 - 8,80	9,05 - 8,85
CO2 - Heat Input max. - G30	%	11,40 - 11,20	11,50 - 11,30	11,40 - 11,20
CO2 - Heat Input min. - G30	%	10,90 - 10,70	10,75 - 10,65	10,75 - 10,55
CO2 - Heat Input max. - G31	%	10,50 - 10,30	10,40 - 10,20	10,55 - 10,35
CO2 - Heat Input min. - G31	%	10,20 - 10	9,95 - 9,85	9,90 - 9,70
CO - Heat Input max.	ppm	67	60	75
CO - Heat Input min.	ppm	1	1	2
Weighted CO (0% O2)	ppm	5	5	7
Casing efficiency losses (Heat Input max.)	%	0,20	0,20	-0,48
Casing efficiency losses (Heat Input min.)	%	-	3,20	1,84
Fumes mass - Heat Input max.	g/s	10,38	12,37	14,96
Fumes mass - Heat Input min.	g/s	1,26	1,78	1,88
NOx class	class	6	6	6
Weighted NOx (0% O2) ppm	ppm	20	21	31
Weighted NOx (0% O2) on GCV mg/kWh	mg/kWh	32	36	49
Central heating circuit				
Temperature setting - Central heating	°C	30-80 / 25-45	30-80 / 25-45	30-80 / 25-45
Max. operating temperature - Central heating	°C	80	80	80
Max. operating pressure - Central heating	bar	3	3	3

2. MAINTENANCE

Model		R2K 24 Rain	R2K 28 Rain	R2K 34 Rain
Min. operating pressure - Central heating	bar	0,3	0,3	0,3
Expansion vessel pre-charge pressure	bar	1	1	1
Available pump head with 1000 l/h flow rate	kPa	0	0	-
Expansion vessel capacity (C.H.)	litres	8	8	8
Domestic Hot Water (D.H.W.) circuit				
Temperature setting - D.H.W.	°C	35-60	35-60	35-60
Max. operating pressure - D.H.W.	bar	6	6	6
Min. operating pressure - D.H.W.	bar	0,5	0,5	0,5
D.H.W. flow rate - continuous flow - Δt 25°C	litres/ min	13,81	16,1	19,2
D.H.W. flow rate - continuous flow - Δt 30°C	litres/ min	11,1	13,4	16
D.H.W. flow rate - continuous flow - Δt 35°C	litres/ min	9,86	11,5	13,7
Dimensions				
Width	mm	420	420	420
Depth	mm	370	370	370
Height	mm	787	787	787
Gross weight	Kg	35	37	39,4
Hydraulic Connections				
C.H. Flow	Ø	3/4"	3/4"	3/4"
Cold water inlet	Ø	1/2"	1/2"	1/2"
D.H.W. outlet	Ø	1/2"	1/2"	1/2"
Gas	Ø	3/4"	3/4"	3/4"
C.H. Return	Ø	3/4"	3/4"	3/4"
Flue systems				
Fan - Max. available pressure	Pa	100	76	91
Fan - Min. available pressure	Pa	21	4	5,8

2. MAINTENANCE

Model		R2K 24 Rain	R2K 28 Rain	R2K 34 Rain
Flue bend 45° MF Ø60/100 - Pressure loss	m	0,6	-	-
Flue bend 90° MF Ø60/100 - Pressure loss	m	1	-	-
Flue extension MF Ø60/100 L=1000 - Pressure loss	m	1	-	-
Flue bend 45° MF Ø80/125 - Pressure loss	m	0,5	-	-
Flue bend 90° MF Ø80/125 - Pressure loss	m	0,8	-	-
Flue extension MF Ø80/125 L=1000 - Pressure loss	m	1	-	-
Max. Flue length Ø50/50 - Horiz. Twin	m	-	12	-
Max. Flue length Ø60/60 - Horiz. Twin	m	-	20	-
Flue adapter Ø80/60 MF - Pressure loss	m	0,4	0,4	0,4
Flue bend 45° MF Ø60 - Pressure loss	m	0,8	0,8	0,8
Flue bend 90° MF Ø60 - Pressure loss	m	1,5	1,5	1,5
Flue extension MF Ø60 L=1000 - Pressure loss	m	1	1	1
T-connection MF Ø60 - Pressure loss	m	3,5	3,5	3,5
Max Flue length Ø80/80 - Horiz. Twin	m	-	60	-
Max. Flue length Ø50 - Horiz. Pipe	m	8	10	3
Max. Flue length Ø60 - Horiz. Pipe	m	30	18	14
Max. Flue length Ø80 - Horiz. Pipe	m	35	35	35
Flue bend 45° MF Ø80 - Pressure loss	m	0,8	0,8	0,8
Flue bend 90° MF Ø80 - Pressure loss	m	1,5	1,5	1,5
Flue extension MF Ø80 L=1000 - Pressure loss	m	1	1	1
T-connection MF Ø80 - Pressure loss	m	3,5	3,5	3,5
Gas supply				
Supply pressure - G20	mbar	20	20	20

2. MAINTENANCE

Model		R2K 24 Rain	R2K 28 Rain	R2K 34 Rain
Supply pressure min. - G20	mbar	17	17	17
Supply pressure max. - G20	mbar	25	25	25
Fan speed Max. HEATING output - G20	Hz	190	192	203
Fan speed Max. D.H.W. output - G20	Hz	190	192	203
Fan speed Min. HEATING output - G20	Hz	50	50	53
Fan speed Min. D.H.W. output - G20	Hz	50	50	53
Gas consumption - G20	m ³ /h	2,49	2,96	3,60
Supply pressure - G30	mbar	28-30	28-30	28-30
Supply pressure min. - G30	mbar	20	20	20
Supply pressure max. - G30	mbar	35	35	35
Fan speed Max. HEATING output - G30	Hz	177	180	195
Fan speed Max. D.H.W. output - G30	Hz	177	180	195
Fan speed Min. HEATING output - G30	Hz	50	50	55
Fan speed Min. D.H.W. output - G30	Hz	50	50	55
Gas consumption - G30	kg/h	1,85	2,21	2,68
Supply pressure - G31	mbar	37	37	37
Supply pressure min. - G31	mbar	25	25	25
Supply pressure max. - G31	mbar	45	45	45
Fan speed Max. HEATING output - G31	Hz	190	190	203
Fan speed Max. D.H.W. output - G31	Hz	190	190	203
Fan speed Min. HEATING output - G31	Hz	50	50	55
Fan speed Min. D.H.W. output - G31	Hz	50	50	55
Gas consumption - G31	kg/h	1,83	2,17	2,64

2. MAINTENANCE

Technical parameters for boiler space heaters, boiler combination heaters and cogeneration space heaters

Model		R2K 24 Rain	R2K 28 Rain	R2K 34 Rain
Condensing boiler	[yes/no]	yes	yes	yes
Low-temperature (**) boiler:	[yes/no]	no	no	no
B11 boiler	[yes/no]	no	no	no
Cogeneration space heater	[yes/no]	no	no	no
If yes, equipped with a supplementary heater	[yes/no]	no	no	no
Combination heater	[yes/no]	yes	yes	yes
Rated heat output Prated	kW	23	27	33
For boiler space heaters and boiler combination heaters: Useful heat output				
At rated heat output and high-temperature regime (*) P ₄	kW	22,9	27,3	33,3
At 30 % of rated heat output and low-temperature regime (**) P ₁	kW	7,6	9,1	11,0
For cogeneration space heaters: Useful heat output				
At rated heat output of cogeneration space heater with supplementary heater disabled P _{CHP100+Sup0}	kW	-	-	-
At rated heat output of cogeneration space heater with supplementary heater enabled P _{CHP100+Sup100}	kW	-	-	-
For cogeneration space heaters: Electrical efficiency				
At rated heat output of cogeneration space heater with supplementary heater disabled η _{el,CHP100+Sup0}	%	-	-	-
At rated heat output of cogeneration space heater with supplementary heater enabled η _{el,CHP100+Sup100}	%	-	-	-

2. MAINTENANCE

Model		R2K 24	R2K 28	R2K 34
		Rain	Rain	Rain
Auxiliary electricity consumption				
At full load elmax	kW	0,038	0,038	0,038
At part load elmin	kW	0,016	0,016	0,016
In standby mode PSB	kW	0,004	0,004	0,004
Seasonal space heating energy efficiency η_s	%	94	94	94
Seasonal space heating energy efficiency class		A	A	A
For boiler space heaters and boiler combination heaters: Useful efficiency				
At rated heat output and high-temperature regime (*) η_4	%	87,5	87,2	88,3
At 30 % of rated heat output and low-temperature regime (**) η_1	%	97,0	97,0	97,8
For cogeneration space heaters: Useful efficiency				
At rated heat output of cogeneration space heater with supplementary heater disabled	%	-	-	-
$\eta_{\text{CHP100+Sup0}}$				
At rated heat output of cogeneration space heater with supplementary heater enabled	%	-	-	-
$\eta_{\text{CHP100+Sup100}}$				
Supplementary heater				
Rated heat output P _{sup}	kW	-	-	-
Type of energy input		-	-	-
Other items				
Standby heat loss P _{stby}	kW	0,059	0,059	0,059
Ignition burner power consumption P _{ign}	kW	0,000	0,000	0,000
Emissions of nitrogen oxides NOx	mg/kWh	32	36	49
Annual energy consumption Q _{HE}	kWh /	20513 /	24422 /	29444 /
	GJ	73,85	87,92	106
Sound power level, indoors L _{WA}	dB	52	52	52


2. MAINTENANCE

Model		R2K 24	R2K 28	R2K 34
		Rain	Rain	Rain
For combination heaters:				
D.H.W. energy efficiency class		A	A	A
Declared load profile		XL	XL	XL
Daily electricity consumption Q_{elec}	kWh	0,146	0,154	0,160
Water heating energy efficiency η_{wh}	%	86	87	87
Daily fuel consumption Q_{fuel}	kWh	23,929	23,660	26,821
Contact details		Tel. +39 0721 9079.1 - fax. +39 0721 9079299 - e-mail: info@radiant.it - http://www.radiant.it		
Name and address of the supplier		RADIANT BRUCIATORI S.p.A. Via Pantanelli, 164/166 - 61025 - Montelabbate (PU)		

(*) High-temperature regime means 60 °C return temperature at heater inlet and 80 °C feed temperature at heater outlet.

(**) Low temperature means for condensing boilers 30 °C, for low-temperature boilers 37 °C and for other heaters 50 °C return temperature (at heater inlet).


2.2.7. TECHNICAL ASSEMBLY



KEY

- | | |
|------------------------------|----------------------------------|
| 1. SYSTEM FILLING TAP | 14. LIGHT UP ELECTRODE |
| 2. INTEGRATED HEAT EXCHANGER | 15. EXPANSION TANK |
| 3. BURNER UNIT | 16. START-UP TRANSFORMER |
| 4. DETECTION ELECTRODE | 17. AIR SUCTION TUBE |
| 5. ELECTRIC FAN | 18. PROPORTIONAL VENTURI |
| 6. AIR RELIEF VALVE | 19. WATER PRESSURE SWITCH |
| 7. SAFETY VALVE 3 bar | 20. CONDENSATE COLLECTION SIPHON |
| 8. MODULATING PUMP | 21. DIVERTER VALVE |
| 9. GAS VALVE | 22. FLOW SWITCH |
| 10. SYSTEM DRAINING TAP | |
| 11. DOMESTIC CIRCUIT PROBE | |
| 12. SAFETY THERMOSTAT | |
| 13. HEATING PROBE | |

R2K 34 RAIN




KEY

- | | |
|------------------------------|-------------------------------------|
| 1. SYSTEM FILLING TAP | 15. EXPANSION TANK |
| 2. INTEGRATED HEAT EXCHANGER | 16. START-UP TRANSFORMER |
| 3. BURNER UNIT | 17. AIR SUCTION TUBE |
| 4. DETECTION ELECTRODE | 18. PROPORTIONAL VENTURI |
| 5. ELECTRIC FAN | 19. WATER PRESSURE SWITCH |
| 6. AIR RELIEF VALVE | 20. CONDENSATE COLLECTION
SIPHON |
| 7. SAFETY VALVE 3 bar | 21. DIVERTER VALVE |
| 8. MODULATING PUMP | 22. FLOW SWITCH |
| 9. GAS VALVE | |
| 10. SYSTEM DRAINING TAP | |
| 11. DOMESTIC CIRCUIT PROBE | |
| 12. SAFETY THERMOSTAT | |
| 13. HEATING PROBE | |
| 14. LIGHT UP ELECTRODE | |

2. MAINTENANCE

2.2.8. HYDRAULIC BOARD




KEY

- | | |
|---------------------------------|-------------------------------------|
| R. HEATING RETURN | 7. CIRCULATOR |
| C. DOMESTIC HOT WATER
OUTLET | 8. SAFETY VALVE 3 bar |
| G. GAS INLET | 9. SYSTEM DRAINING TAP |
| SC. CONDENSATE DRAIN | 10. GAS VALVE |
| F. COLD WATER INLET | 11. DOMESTIC CIRCUIT PROBE |
| A. HEATING FORWARD | 12. SAFETY THERMOSTAT |
| 1. FUMES SAFETY THERMOFUSE | 13. HEATING PROBE |
| 2. INTEGRATED HEAT
EXCHANGER | 14. EXPANSION TANK |
| 3. BURNER UNIT | 15. AIR SUCTION TUBE |
| 4. ELECTRIC FAN | 16. PROPORTIONAL VENTURI |
| 5. BY-PASS | 17. CONDENSATE COLLECTION
SIPHON |
| 6. AIR RELIEF VALVE | 18. DIVERTER VALVE |
| | 19. FLOW SWITCH |
| | 20. WATER PRESSURE SWITCH |
| | 21. SYSTEM FILLING TAP |

2. MAINTENANCE

2.2.9. WIRING DIAGRAM

SERVICE CENTRE



ER: DETECTION ELECTRODE

TS: SAFETY THERMOSTAT

MP: PANEL TERMINAL

CE: BLUE

EA: START-UP ELECTRODE

PACQ: WATER PRESSURE SWITCH

SE: EXTERNAL PROBE

MA: BROWN

PM: MODULATING PUMP

MF: MICRO-FLOW SWITCH

TA: ENVIRONMENT THERMOSTAT

AR: ORANGE

VG: GAS VALVE

SR: HEATING PROBE

L: LINE

GI: YELLOW

TRA: START-UP TRANSFORMER

SS: DOMESTIC CIRCUIT PROBE

N: NEUTRAL

BI: WHITE

TF: FUMES THERMOFUSE (102°C)

EV: ELECTRIC FAN

NE: BLACK

GR: GREY

VD: DIVERTER VALVE

SRI: RETURN SENSOR

2.2.10. ACCESSING THE BOILER

For most control and maintenance operations, the panels of the casing have to be removed.

To remove the panel of the boiler, please follow the instructions below (see fig.1):


- > remove the fastening screws (1) placed on the side of the panel flange and remove it;
- > remove the fastening screws (2) placed on the upper and lower side of the panel, and remove it by pulling it towards yourself;
- > remove the fastening screws (3) placed on the lower side of the boiler and remove the connection cover.

To intervene on the front of the boiler, please proceed as follows:

- > remove the fastening screws (4) placed on the front panel;
- > grab the front panel and remove it by pulling it towards yourself;

To intervene on the side panels of the boiler, please proceed as follows:

- > remove the fastening screws (5) placed on the front edge of the side panel;
- > grab the bottom of the panel, and remove it by moving it sideways and pulling it upwards.



2. MAINTENANCE

2.2.11. ACCESSING THE ELECTRONIC BOARD


In order to intervene on the wirings of the control panel, please proceed as follows:



DANGER

Cut off the voltage from the main switch.

- > Grab at the same time the support brackets of the control panel (fig. 1) loosening them and turn the panel downwards;
- > unscrew the four fastening screws 1 - fig. 1;
- > remove the crankcase pulling it upwards.




2.2.12. SYSTEM EMPTYING

HEATING SYSTEM EMPTYING

Whenever you need to empty the system, proceed as follows:

- › switch the boiler to “WINTER” mode and activate it;
- › turn off the main power supply switch;
- › wait for the boiler to cool down;
- › connect a flexible tube to the system emptying outlet and connect the other end of the tube to a suitable discharge;
- › turn the discharge tap of the system ‘RS’ (fig. 1);
- › open the relief valves of the radiators starting from the one at the top and continuing downwards;
- › after draining out all water, close the relief valves of the radiators and the emptying tap.



EMPTYING THE DOMESTIC SYSTEM

If there is freezing risk, you have to empty the domestic system as follows:

- › close the main supply tap of the water supply network;
- › open all cold and hot water taps;
- › after completing all operations, close the discharge tap and all previously opened water taps.

2. MAINTENANCE

2.2.13. GAS CONVERSION



ATTENTION

Make sure that the gas adduction tube is suitable for the new type of fuel with which the boiler is supplied.

- › loosen the two screws '1' (fig.1) from the fastening bush, and remove the air suction tube;
- › unscrew the tube coupling that connects the gas valve to venturi;
- › unscrew the three fastening screws '2' (fig.1) of the venturi 'V' (fig.1) using a 10 key, as shown in figure 2;
- › remove the two screws '3' (fig.3) and apply pressure on the rear side of venturi 'C' (fig.3);
- › replace the body venturi with the one suitable for the type of supply gas (for 24 kW cod. 30-00231 for Natural gas / cod. 30-00170 for Universal LPG) (for 28 kW cod. 30-00232 per metano / cod. 30-00169 per GPL) (for 34 kW cod. 30-00207 per metano / cod. 30-00201 per GPL) and make sure the tooth 'D' (fig.3) is adjusted downwards on the aluminium ring nut (see fig.3);
- › remount the components following the demounting operations in reverse making sure that gasket 'G' is re-assembled as shown in fig.1;




fig. 1




fig. 2




fig. 3

- > set the boiler to operate with the new type of gas, changing the value of the parameter P02 'GAS TYPE SELECTION' from the control panel (see chapters 'DIGITECH CS PARAMETERS TABLE' and 'ACCESSING AND PROGRAMMING THE PARAMETERS');
- > adjust the CO₂ combustion value as indicated in chapter 'CO₂ VALUE CHECK AND CALIBRATION'.

3. USER SECTION

The operations described in this section are addressed to all those who will use the machine. The machine must be used and accessed only by qualified operators that fully read and understood the User section, paying particular attention to the warnings.

3.1. USE

3.1.1. GENERAL USE WARNINGS



WARNING

Before starting the boiler the User must make sure that the First start-up certificate has the stamp of the technical Support Centre proving the testing and the first start-up of the boiler.



WARNING

In order to take advantage of the guarantee provided by the manufacturer, the customer should carefully and exclusively observe the instructions given in the USER section of the manual.



ATTENTION

This machine may be used only for the purpose for which it has been designed: heat water to a temperature below boiling point at atmospheric pressure. Any other use is considered wrong and dangerous. The manufacturer is excluded from any contractual or out of contract responsibility for damage caused to people, animals or property due to incorrect use.



DANGER

The boiler should not be used by persons (including children) with reduced physical, sensory or mental capacities or without suitable knowledge or experience unless they are instructed on the device use or monitored by a person responsible for their safety.



DANGER

DO NOT obstruct the air vents of the location in which the gas device is installed to prevent the formation of toxic explosive mixes.



DANGER

If you sense a gas odour in the location in which the boiler is installed, proceed as follows:

- > DO NOT use electrical switches, the telephone or any other device that might generate electrical discharges or sparks;
- > Immediately open all doors and windows to create an air exchange that can quickly clean the location;
- > Close the gas valves;
- > Request immediate intervention of qualified staff.




DANGER

The use of the electrical power boiler implies respecting some fundamental rules such as:

- › DO NOT touch the device with wet and/or humid parts and/or with bare feet;
- › DO NOT pull the electrical cables;
- › DO NOT leave the device exposed to atmospheric agents (rain, sun, etc.) unless specifically intended;
- › in case of cable damage, turn off the device and contact qualified professional staff to replace it.

3. USE

3.1.2. CONTROL PANEL



KEY



1. HEATING TEMPERATURE ADJUSTMENT KEYS
2. INFO KEY: PRESS ONCE TO VIEW THE TEMPERATURES AND OTHER INFORMATION (see chapter 'INFO MENU DISPLAY') - HOLD FOR 5 SECONDS, IN OFF OPERATING MODE, TO VIEW THE LAST 5 FAULTS
3. OPERATING MODE SELECTION KEY: SUMMER / ONLY HEATING / WINTER / OFF
4. RESET KEY: FAULTS RESET - CHIMNEY SWEEP FUNCTION ACTIVATION (HOLD FOR 7 SECONDS)
5. DOMESTIC HOT WATER TEMPERATURE ADJUSTMENT KEY / HOLD THE KEYS AT THE SAME TIME FOR 5 SECONDS TO ACTIVATE DISPLAY BACK LIGHT FOR 10 MINUTES
6. DISPLAY

3. USE

3.1.3. DISPLAY ICONS






KEY

1. INDICATION OF PARAMETER NUMBER OR DISPLAYED INFO CODE
2. PARAMETERS PROGRAMMING FUNCTION ACTIVE
3. SIGNALLING CONNECTED SOLAR BOARD / SOLAR COLLECTOR TEMPERATURE DISPLAY (d5)
4. SOLAR PUMP ACTIVE
5. BOILER LOWER TEMPERATURE DISPLAY (d6) / BOILER UPPER TEMPERATURE DISPLAY (d7)
6. EXTERNAL PROBE INSTALLED / EXTERNAL PROBE TEMPERATURE (d1)
7. TEMPERATURE DISPLAY / SET POINT / PARAMETER VALUE
8. OPENTHERMCOMMUNICATION PRESENT (REMOTE CONTROL / AREA CONTROL UNIT)
9. INSUFFICIENT SYSTEM WATER PRESSURE SIGNALLING
10. FLAME PRESENT SIGNALLING / IT ALSO INDICATES, ON 3 PERCENTAGE LEVELS, THE MODULATING POWER LEVEL OF THE BOILER (fig.2)
11. OPERATION IN DOMESTIC MODE ENABLED
12. ERROR DISPLAY THAT CAN BE RESET
13. OFF OPERATING MODE
14. ERROR DISPLAY THAT CAN NOT BE RESET
15. OPERATION IN HEATING MODE ENABLED








3. USE

3.1.4. INFO MENU DISPLAY DATA

To view the boiler data from info menu you just have to press the INFO  key. The info code will be displayed on the left side of the screen and its relative value will be displayed on the centre of the screen. Use keys  and  of the heating circuit  to scroll through the list of displayed data. To exit display mode press the INFO  key.

LIST OF DISPLAYED DATA

INFO CODE	ICON	DESCRIPTION
d0		DOMESTIC CIRCUIT PROBE TEMPERATURE
d1		EXTERNAL PROBE TEMPERATURE
d2		FAN SPEED
d3		BOTTOM AREA PROBE TEMPERATURE [IF AREA BOARD INSTALLED]
d4		RETURN PROBE TEMPERATURE
d5		SOLAR COLLECTOR TEMPERATURE [IF SOLAR BOARD INSTALLED] (SCS)
d6		SOLAR BOILER TEMPERATURE (BOTTOM) [IF SOLAR BOARD INSTALLED] (SBSI)
d7		SOLAR BOILER TEMPERATURE (TOP) [IF SOLAR BOARD INSTALLED] (SBSS)

3. USE

I N F O

CODE	ICON	DESCRIPTION
------	------	-------------

d8



SOLAR COLLECTOR PROBE TEMPERATURE 2 [IF SOLAR BOARD INSTALLED] (SCS2)

d9



EXTRA SOLAR BOILER TEMPERATURE [IF SOLAR BOARD INSTALLED] (SBS3)

dA

INERTIAL STORAGE SENSOR TEMPERATURE

dB

LOW-TEMPERATURE HEATING CIRCUIT RETURN SENSOR TEMPERATURE (IN HYBRID SYSTEM BOX MODE) - HEATING PUMP RETURN SENSOR TEMPERATURE (IN HYBRID DOMESTIC SYSTEM MODE)

dC

HYBRID SYSTEM BOX D.H.W. TANK SENSOR TEMPERATURE - HOT WATER TEMPERATURE OUT OF THE REMOTE TANK TO THE BOILER (ONLY FOR HYBRID DOMESTIC SYSTEM WITH OPTIONAL SENSOR)

dD


POWER SUPPLIED BY THE HEATING PUMP IN KW/H (ONLY FOR HYBRID DOMESTIC SYSTEM)

dE

HEATING FLOW RATE DISPLAY EXPRESSED IN L/MIN (IF THERE IS A FLOWMETER).

3.1.5. START-UP



Before starting the boiler make sure that it is powered and that the gas tap below the boiler is open.


To start the boiler press the function key  and select the desired operating mode. If the symbol is displayed fixed, it means that the function was activated.

3.1.6. OPERATING MODE

SUMMER MODE



In this mode the boiler meets only the demands of domestic hot water.

To switch the boiler to SUMMER operating mode, press the function key , the symbol  will appear fixed on the display, indicating that the function is enabled.


Whenever hot domestic water is needed the automatic start-up system will start the burner; this is indicated by displaying the symbol  blinking.

ONLY HEATING MODE

In this mode the boiler meets only the demands of heating.




To switch the boiler to ONLY HEATING operating mode, press the function key , the symbol  will



appear fixed on the display, indicating that the function is enabled.

Whenever heating energy is needed to heat the rooms the automatic start-up system will start the burner; this is indicated by displaying the symbol  blinking.




WINTER MODE



In this mode the boiler meets the demands of heating and of domestic hot water.

To switch the boiler to WINTER operating mode, press the function key , the symbols  and  will appear fixed on the display, indicating that the function is enabled.

Whenever heating energy and domestic hot water are needed the automatic start-up system will start the burner; this is indicated by displaying the symbol  and  blinking.




ADJUSTING THE HEATING TEMPERATURE



You can adjust the temperature using keys  and  of the heating circuit :

- press key  to decrease the temperature.
- press key  to increase the temperature.

The heating temperature adjustment field ranges from 30 °C to 80 °C (25 °C – 45 °C for floor systems).

DOMESTIC HOT WATER TEMPERATURE ADJUSTMENT



You can adjust the temperature using keys  and  of the domestic circuit :

- press key  to decrease the temperature.
- press key  to increase the temperature.

The hot domestic water temperature adjustment field ranges from 35 °C to 60 °C.

OFF MODE

In this mode the boiler no longer meets the heating and domestic hot water demands, the anti-freeze, pump anti-locking and diverter valve anti-locking systems still remain active.

To switch the boiler to OFF operating mode, press the function key , the symbol  will appear fixed on the display, indicating that the function is enabled (for non condensing models will appear the message 'OFF').

If the boiler was previously running, it will be turned off and the post-

ventilation and post-circulation functions will be enabled.

If you have to deactivate the boiler for a long period of time, proceed as follows:

- > contact the Technical support centre that will empty the water system, where no anti-freeze is intended, and will cut off the power, water and gas supply.
- > Or leave the boiler in OFF operating mode keeping active the electrical and gas supplies so that the anti-freeze function may activate.

3.1.7. INFORMATIONAL NOTE ON ANTI- FREEZE FUNCTION

The boiler is protected against freezing thanks to the electronic board preparation with functions that start the burner and heat the concerned parts when their temperature goes below the minimum pre-set values.



WARNING

This function is available


only if:

- › the boiler is powered;
- › the gas supply is open;
- › the pressure of the system is proper;
- › the boiler is not blocked.

3.1.8. SYSTEM FILLING

To restore the water pressure inside the system open the loading tap "R" (fig. 1) and make sure using pressure gauge "M" (fig. 1), that the system pressure reaches 1.2 bar (see fig. 2). After performing this operation, make sure that the loading tap "R" (fig. 1) is properly closed.



After the water pressure reset the boiler will automatically perform a 2 minutes system relief cycle. Throughout this function the display will show the code "F33". The boiler can work normally only after completing the operation.



3. USE

3.1.9. FAULT SIGNALLING CODES


The boiler might signal some faults by displaying a code. Below you have a list of the codes and of the operations to be performed in order to unlock the boiler.

CODE	ICON	FAULT	INTERVENTION
E01	RESET	FLAME BLOCK	<p>MAKE SURE THAT THE BOILER AND CONTACTOR GAS VALVES ARE OPEN.</p> <p>PRESS THE RESET  BUTTON ON THE CONTROL PANEL TO RESET THE FAULT, AS SOON AS THE ERROR CODE DISAPPEARS FROM THE DISPLAY, THE BOILER WILL START AUTOMATICALLY.</p> <p>IF THE BLOCK PERSISTS CONTACT THE TECHNICAL SUPPORT CENTRE.</p>
E02	RESET	SAFETY THERMOSTAT (95 °C)	<p>CONTACT THE TECHNICAL SUPPORT CENTRE.</p>
E03	RESET	FUMES SAFETY THERMOFUSE (102 °C)	<p>CONTACT THE TECHNICAL SUPPORT CENTRE.</p>
E04	 Low	WATER MISSING IN THE SYSTEM	<p>IF THE SYSTEM PRESSURE IS BELOW 1.2 BAR, FILL THE SYSTEM AS DESCRIBED IN CHAPTER "SYSTEM FILLING".</p> <p>IF THE BLOCK PERSISTS CONTACT THE TECHNICAL SUPPORT CENTRE.</p>




3. USE

CODE	ICON	FAULT	INTERVENTION
E05	SERVICE	HEATING PROBE	CONTACT THE TECHNICAL SUPPORT CENTRE.
E06	SERVICE	DOMESTIC CIRCUIT PROBE	CONTACT THE TECHNICAL SUPPORT CENTRE.
E10	SERVICE	LOW FLOW RATE	CONTACT THE TECHNICAL SUPPORT CENTRE.
E14	SERVICE	AIR PRESSURE SWITCH	CONTACT THE TECHNICAL SUPPORT CENTRE.
E15	SERVICE	RETURN PROBE	CONTACT THE TECHNICAL SUPPORT CENTRE.
E16	SERVICE	ELECTRIC FAN	CONTACT THE TECHNICAL SUPPORT CENTRE.
E18	SERVICE	INSUFFICIENT CIRCULATION	CONTACT THE TECHNICAL SUPPORT CENTRE.
E21	SERVICE	ELECTRIC LEAKAGE ON THE HIGH CIRCUIT VOLTAGE / ELECTRICAL NOISE DUE TO SPARK DISCHARGE	CUT OFF THE POWER SUPPLY FROM THE MAIN SWITCH AND THEN RESTORE IT, AS SOON AS THE ERROR CODE DISAPPEARS, THE BOILER WILL RESTART AUTOMATICALLY. IF THE BLOCK PERSISTS CONTACT THE TECHNICAL SUPPORT CENTRE.

3. USE

CODE	ICON	FAULT	INTERVENTION
E22	SERVICE	PARAMETERS PROGRAMMING REQUEST	CUT OFF THE POWER SUPPLY FROM THE MAIN SWITCH AND THEN RESTORE IT, AS SOON AS THE ERROR CODE DISAPPEARS, THE BOILER WILL RESTART AUTOMATICALLY. IF THE BLOCK PERSISTS CONTACT THE TECHNICAL SUPPORT CENTRE.
E31	SERVICE	INCOMPATIBLE REMOTE CONTROL	CONTACT THE TECHNICAL SUPPORT CENTRE.
E32	SERVICE	COMMUNICATION ERROR BETWEEN THE BOILER BOARD AND THE MODBUS BOARD	CONTACT THE TECHNICAL SUPPORT CENTRE.
E35	RESET	RESIDUAL FLAME	PRESS THE RESET  BUTTON ON THE CONTROL PANEL TO RESET THE FAULT, AS SOON AS THE ERROR CODE DISAPPEARS FROM THE DISPLAY, THE BOILER WILL START AUTOMATICALLY.
E40	SERVICE	SUPPLY VOLTAGE	CONTACT THE TECHNICAL SUPPORT CENTRE.
E52	SERVICE	COMMUNICATION FAULT BETWEEN MODBUS CONTROLLER AND MODBUS CONTROL UNIT	CONTACT THE TECHNICAL SUPPORT CENTRE.

3.1.10. ACTIVE FUNCTIONS SIGNALLING CODES

CODE	FUNCTION	INTERVENTION
F08	HEATING ANTI-FREEZE FUNCTION ACTIVE	WAIT UNTIL THE OPERATION IS COMPLETED
F09	D.H.W CIRCUIT ANTI-FREEZE FUNCTION ACTIVE	WAIT UNTIL THE OPERATION IS COMPLETED
F33	SYSTEM AIR RELEASE CYCLE IN PROGRESS	WAIT UNTIL THE OPERATION IS COMPLETED
FH	FAST H2O	YOU CAN ACTIVATE/DEACTIVATED IT BY HOLDING SIMULTANEOUSLY AND FOR 7 SECONDS THE RESET  AND  OF THE DOMESTIC CIRCUIT  .

3.1.11. FAST H2O FUNCTION

The Fast H2O function keeps a constant temperature in the DHW circuit within the boiler, according to the temperature set by the user.

The Fast H2O function offers three advantages:

- > the hot water is immediately supplied at the requested temperature.
- > unnecessary delays are avoided by increasing the comfort of the final user.
- > water wastes are limited waiting that the water reaches the right temperature.

To activate/deactivate the Fast H2O function please follow the instruction indicated in the paragraph 'ACTIVE FUNCTIONS SIGNALLING CODES'.

3. USE

3.1.12. MAINTENANCE

To ensure proper boiler safety and efficiency, please contact RADIANT technical support network to check the device every year.

An accurate maintenance should improve system management.

indicates that this product can not be dismantled as domestic waste. Proper disposal of this product helps preventing potentially negative consequences for the environment and person's health.

3.1.13. EXTERNAL CASING CLEANING

Clean the cover of the device using a wet cloth and come neutral soap.



WARNING

DO NOT use abrasive or powder detergents as they might damage the plastic cover and control elements.

3.1.14. DISPOSAL

The boiler and all its accessories must be disposed of by differentiating them appropriately according to the recycling regulation in force.



The use of the symbol WEEE (Waste Electrical and Electronic Equipment)

